

So, Here's The Technical Bit...

The cold water from your water supply passes through the filter into the 3.5L boiler. The water temperature can be easily adjusted from 25°C - 98°C to suit your requirements by simply turning the dial located at the front of the boiler.

For steaming water use the smaller lever on the left hand side of the tap. Push down the lever to release the child safety mechanism then turn and hold to start a steady flow of steaming water, when you are finished the unique spring loaded lever automatically shuts off the steaming water.

It couldn't be easier to change the filter. There is no need to cut off the water supply, just twist the used filter to release it - this automatically isolates the water supply making it easy to twist the new cartridge into place.

All Caple accessories, including replacement filters and fixing kits, are available to buy at www.caple.co.uk for next day delivery.

